
OBSERVATION/ MAINTENANCE PORT

PORT USED FOR INSPECTION PURPOSES AND FOR SYSTEM MAINTENANCE AS REQUIRED. WATER SHALL BE PUMPED INTO THE SYSTEM AND RESUSPEND ACCUMULATED SEDIMENT. MINIMUM REQUIRED MAINTENANCE INCLUDES A QUARTERLY INSPECTION FOR THE FIRST YEAR OF OPERATION AND A YEARLY INSPECTION THEREAFTER FLUSH AS NEEDED.



FOCALPOINT OBSERVATION/ MAINTENANCE PORT



NOTCH PATTERN AT BOTTOM OF PIPE (SEE NOTCH PATTERN DETAIL)

PIPE NOTCH PATTERN DETAIL

4"-9" CUT IN SHADED AREAS

TO FIND A VALUE ADDED RESELLER IN YOUR AREA VISIT WWW.CONVERGENTWATER.COM/STORMWATER-PRODUCTS OR CONTACT CONVERGENT WATER TECHNOLOGIES AT 1.800.771.5428

